

Overview for service sheet - Model W204

Jobs to be carried out by MBV authorized workshops.	Service A Every 10,000 km	Service B Every 20,000 km	Completed	Remarks
General items				
Service display in instrument cluster reset	x	x	<input type="checkbox"/>	
Function tests: indicator lamps in instrument cluster and interior illumination, windshield wiper, windshield washer system, headlamp cleaning system, headlamp system, trunk light, turn signal light, horns, steering system, heater & air conditioning.	x	x	<input type="checkbox"/>	
All components: Checking for leaks and damage, if evidence of fluid loss is detected, determine cause and correct subject to separate order	x	x	<input type="checkbox"/>	
Brake system, wheels				
Check brake pads for thickness and replace if necessary	x	x	<input type="checkbox"/>	
Check brake condition and correct fluid level, if fluid loss is discovered, determine and rectify the cause to separate order	x	x	<input type="checkbox"/>	
Check condition of brake discs for wear limit and replace if necessary		x	<input type="checkbox"/>	
Brake test on test stand and record brake values in KN		x	<input type="checkbox"/>	
Tires checked for damage & cracking, tyre tread depth measured. Correct tyre inflation pressure and enter bars or psi		x	<input type="checkbox"/>	
Wheels: Check & retighten nuts according to condition		x	<input type="checkbox"/>	
Engine compartment				
Engine oil and filter replacement	x	x	<input type="checkbox"/>	
Visual check intake line between air cleaner and engine for leaks	x	x	<input type="checkbox"/>	
Air cleaner with paper element: check contamination and replace if necessary	x	x	<input type="checkbox"/>	
Check and correct fluid level of coolant, power steering, windshield washer system. If fluid loss is discovered, determine and rectify the cause	x	x	<input type="checkbox"/>	
Check visible area of poly-V belt for wear and replace as necessary		x	<input type="checkbox"/>	
Check and correct battery liquid level	x	x	<input type="checkbox"/>	
Check condition of battery poles & cable for looseness	x	x	<input type="checkbox"/>	
Chassis and body				
Front axle joints checked for play, rubber gaiters inspected		x	<input type="checkbox"/>	
Check condition of flexible couplings		x	<input type="checkbox"/>	
Check tight fit of nuts and bolts, retighten according to condition.		x	<input type="checkbox"/>	
Check steering condition of the steering linkage		x	<input type="checkbox"/>	
Check wiper rubber and replace if necessary	x	x	<input type="checkbox"/>	
Check air filter for A/C and replace if clogged.		x	<input type="checkbox"/>	
Check body for paint damage		x	<input type="checkbox"/>	
Additional works				
Replace brake fluid	Every 2 years		<input type="checkbox"/>	
Replace engine air filter element	Every 50,000 km/ 3 years		<input type="checkbox"/>	
Automatic transmission oil change and filter replacement	Every 50,000 km/ 3 years		<input type="checkbox"/>	
Replace spark plugs	Every 60,000Km/4 years (*)		<input type="checkbox"/>	
Fuel filters replacement (May be replaced earlier if fuel quality with high contamination)	Every 80,000 km/ 4 years (*)		<input type="checkbox"/>	
A/C air filter replacement	Every 50,000 km/ 3 years (*)		<input type="checkbox"/>	
Renewing coolant	15 years or every 250,000 km		<input type="checkbox"/>	